



Ice Machine

Cleaning & Sanitizing


HOSHIZAKI

KMS-1122MLH(3)

The icemaker must be cleaned & sanitized at least once a year.

Cleaning Prep:

- 1 Remove the **Front Panel**, move the **control switch** to **OFF**. After **3 min.**, move the **control switch** to **ICE**, then replace the **Front Panel**.
 - 2 After **3 min.**, remove the **Front Panel**, move the **control switch** to **OFF**. This removes the cubes from the evaporator.
 - 3 Remove all ice from the dispenser unit/ice storage bin.
- ! ATTENTION! IF ON DISPENSER**, turn off the dispenser power supply after dispensing all the ice.



! ATTENTION!

Do not leave icemaker unattended when panels are off



Sanitizing:


- Dilute 5.25% chlorine bleach* with warm water (see Table below)

KMS-1122MLH(3)	
Bleach	2.5 fl. oz (74 ml)
Warm Water	5 gal. (19 l)


* Use bleach without additives.

- 15 Dilute 5.25% chlorine bleach* with warm water (see Table below)
- 16 Remove the front, apron, top, left, & left insulation panels
- 16 Pour the sanitizing solution into the water tank
- 16 Replace all the panels, except the front panel
- 17 Move **service switch** to **WASH** and **control switch** to **SERVICE**, replace the front panel
- 18 After 15 minutes, remove front panel
- 18 Move **service switch** to **DRAIN**, replace the front panel
- 19 After 2 minutes, remove front panel
- 19 Move **control switch** to **OFF**

Cleaning:



- 4 Remove the **Front Panel**, move the **service switch** to **DRAIN**. Move **control switch** to **SERVICE**. Replace the **Front Panel**.
- 5 After **2 minutes**, remove the **Front Panel**, move the **control switch** to **OFF**.
- 6 Dilute Hoshizaki **Scale Away** with warm water (see Table below). Remove the **Front, Apron, Top, Left, & Left Insulation Panels** and pour cleaning solution into the water tank.




KMS-1122MLH(3)	
Scale Away	27 fl. oz (800 ml)
Warm Water	5 gal. (19 l)

- 7 In bad water conditions, a more thorough cleaning may be required. Move **control switch** to OFF, then turn off the power supply. Dilute **5 oz. of Scale Away to 1 gallon of warm water**. Remove and clean the float switch assembly*, water supply tubes, spray tubes, and spray guides. Rinse thoroughly, then replace in their correct positions. Turn the power supply back on. Otherwise, continue to Step 8.

* Remove retainer rod (take care not to bend excessively) from bottom of the float switch housing & clean all float parts.


- 8 Replace all the **Panels**, except the **Front Panel**. Move the **service switch** to **WASH**, and the **control switch** to **SERVICE**. Replace the **Front Panel**.
- 9 After **30 minutes**, remove the **Front Panel**, move the **service switch** to **DRAIN**. Replace the **Front Panel**.

ATTENTION! To prevent damage to the water pump, do not leave the control switch on SERVICE for extended periods when water tank is empty.



Cleaning Rinse:

- 10 After **2 minutes**, remove the **Front Panel**, move the **control switch** to **ICE**. Replace the **Front Panel**.
- 11 After **3 minutes**, move the **service switch** to **WASH**, and the **control switch** to **SERVICE**. Replace the **Front Panel**.
- 12 After **5 minutes**, remove the **Front Panel**, move the **service switch** to **DRAIN**. Replace the **Front Panel**.
- 13 After **2 minutes**, remove the **Front Panel**, move the **control switch** to **OFF**.
- 14 Repeat 3x (Steps 10 thru 13) to rinse thoroughly. Continue to **Sanitation – Step 15 on front...**



↓ sanitizing continued...

RINSE 1: (Steps 20-22)

- 20 Move **control switch** to **ICE**, replace front panel
- After 3 minutes, remove the front panel
- 21 Move **service switch** to **WASH** and **control switch** to **SERVICE**, replace the front panel
- After 5 minutes, remove the front panel
- 22 Move **service switch** to **DRAIN**, replace the front panel
- After 2 minutes, remove the front panel
- Move **control switch** to **OFF**, replace the front panel

RINSE 2:

- 23 Repeat RINSE 1 (Steps 20–22) for complete ice/food safety
- 24 Clean the dispenser unit / ice storage bin liner with a neutral cleaner (dish soap)
- Rinse thoroughly
- 25 Move **control switch** to **ICE**, replace front panel

DOWNLOAD COMPLETE INSTRUCTION MANUAL:



hoshizakiamerica.com/manuals

Type in the model number of your icemaker (including dashes) to download manuals

CLEANING SCHEDULE

● Scoop	Dish soap, rinse well
● Water Filters	Check psi, change if req'd
● Exterior	Dish soap & damp cloth
● Bin Door/Top Kit	Warm water & clean cloth
● Icemaker/Bin	Follow these instructions
● Water Supply Inlet	Clean inlet screen
● Condenser	Inspect. Clean with brush
● Water Hoses	Inspect. Replace if req'd
● DAILY ● MONTHLY ● YEARLY	

ATTENTION!

DO NOT use ammonia type cleaners. Can cause damage to icemaker

WEAR liquid-proof gloves and goggles to protect skin & eyes from cleaning & sanitizing chemicals

ATTENTION!

IF ICEMAKER IS ON DISPENSER, remember to turn on the dispenser after cleaning